

OPOS Setup Intruction.

Supported models:

AS8120/8150/8250/8310/8510/8520/8000CL/8020CL.

1. Prepare scanners:

A. Make sure scanners cables are RS232 or USB (with C mark) .

- i. **Please Note that HID cable (without C mark) does not support OPOS application.**



- ii. **C mark cable:**

B. Config scanner to adapted to OPOS application with following:

- i. Program: 

Default: 

- ii. Program: 

Baud: 

Interface: 

Exit: 

C. If you need to displace barcode type: turn on this option

- i. On 

D. If you do not want to display barcode type: turn off this option

- i. Off 


2. If you are using USB (with C mark) cable, install virtual com driver from C:\Program files\ARGOX\ArgoxOpos\vcom_driver\, or execute C:\Program

files\ARGOX\ArgoxOpos\vcom_driver\CP210xVCPInstaller.exe directly.

3. Find out which com port scanner is connected to.
4. Execute C:\Program files\ARGOX\ArgoxOpos\ComSetup.exe to generate appropriate ComSetup.ini, so ArgoxApplication.exe can read scanner through OPOS driver.
 - A. **Please note that do not change Baud, Parity, Data bit, and Stop bit, or you may cause a connection problem.**
 - i. **Baud:38400, Parity:None, Data bit:8, Stop bit:1**



5. OPOS methods:
CheckHealth,ClearInput,ClearInputProperties,ClearOutput,DirectIO,ResetStatistics,RetrieveStatistics,UpdateStatistics are no Supported.
6. Claim method may take several seconds to obtain scanner information. All of Source code are packed into ArgoxApplication.zip



Scanning Result:

