
PT-60_F_Upgrade firmware procedure

Copy bin file to PT-60 have two options:

Flash disk must be TFAT format.

Option 1

- 1. Copy the bin file(CE506.bin) to SDMMC card.
- 2. Insert the SD card into PT-60 series.
- 3. Enter My Device\SD_MMC copy the bin file(CE506.bin) to Flash Disk.



- 4. When file transfer is complete ,please check the bin
- 5. Goto upgrade firmware procedure.(in page 4)

Option 2

1. Argox download center down Active sync4.5 and PT-60

Users_Manual

- 2. Setup Active sync4.5
- Connecting the PT-60 to ActiveSync (PT-60 Users_Manual chapter 7 Communication)
- 4. From PC Copy the bin file(CE506.bin) to PT-60 Flash disk.





- 5. Check the bin file(CE506.bin) in PT-60's Flash Disk.
- 6. Go to upgrade firmware procedure.(in page 4)

Upgrade firmware procedure

- 1. Do cold reset (press power key and reset key at the same time).
- 2. Then press Func key and 0 key Immediately.
- 3. The screen will show information like picture 1.
- 4. Press enter key to start upgrade.



picture 1 picture 2

- 5. After press enter key, it will start to upgrade like picture 2.
- 6. After upgrade, it will enter OS system.

PS. If it shows error message [Read File Error], please format Flash disk in TFAT format again.