

The barcodes in this manual is from AI-6821's user manual.

If the picture is not clearly, please download user manual from Argox website.

1. Scan suffix 1.

■ Suffix 1

Add one character at the end of your bar code.

Option	Description	Bar Code
00-FF	Suffix length: one character Default: 0x0D	



2. Scan 0.

3. Scan D.

4. Scan Save.

5. Scan Sending data + suffix 1 to enable suffix 1.

Appendix D. Data entry bar codes



9



0



A



B



C



D



E



F



Save



Cancel



suffix 1 Sending data + suffix 1

