



AS-8060 Quick Start Guide



This manual is simplified, for detail manual information please download the completed user manual from our website or obtain it from our distributor.

Factory Default



Note: Default interface: USB-HID
Setting Procedure:
Scan required barcodes
Example: Factory default, USB-HID, add suffix "Enter" ect barcode as below

1 Factory Default



2 Enter



Interfaces



Scan Mode



Buzzer



Image Inverted



Keyboard Language



Suffix Setting



Rs232 Baud Rate Setting



Barcode Setting



警告使用者:
這是甲類的資訊產品, 在居住的環境中使用時, 可能會造成射頻干擾, 在這種情況下, 使用者會被要求採取某些適當的對策。

設備名稱: 條碼閱讀器 Equipment name	型號(型號): AS-8060 Type designation (Type)					
	鉛Lead (Pb)	汞Mercury (Hg)	鎘Cadmium (Cd)	六價鉻Hexavalent chromium (Cr ^{VI})	多溴聯苯 Polybrominated biphenyls (PBB)	多溴二苯醚 Polybrominated diphenyl ethers (PBDE)
印刷電路板組件	○	○	○	○	○	○
機殼	○	○	○	○	○	○
線材	○	○	○	○	○	○
標籤紙	○	○	○	○	○	○

備註1: "○" 標誌該項限制物質之百分比含量未超過百分比含量基準值。
備註2: "○" 標誌該項限制物質為豁免項目。
備註3: "○" 標誌該項限制物質之百分比含量未超過百分比含量基準值。
備註4: "○" 標誌該項限制物質為豁免項目。

Publish Date: Aug. 2019