

I4 / DX Series

Wi-Fi Installation Guide

Part No: 49-I2502-001 Revision Date: Nov. 2016

Note:

*Specifications, accessories, parts and programs are subject to change without notice.

Argox Information Co., Ltd.

7F., No.126, Ln.235, Baoqiao Rd., Xindian Dist., New Taipei City 231, Taiwan (R.O.C.) Tel: +886-2-8912-1121 Fax: +886-2-8912-1124 http://www.argox.com

Copyright © 2016. Argox Information Co., Ltd. All Rights Reserved.



START Wi-Fi Board Parallel Connector Wi-Fi Connector Plastic Washer Antenna Cable Toothed Washer 13 Hex Wrench (Spec: 8mm) Antenna must be fixed tightly Hex Nut Wi-Fi Board Antenna Cable 18 16 ⚠ Caution: Be careful with the steps because the antenna mount is quite fragile. The antenna may break if you use excessive force when pushing or pulling it.